



2024

Product Catalog





Buckeye Poly Furniture is a family business that is owned by Aden and Michael Troyer. The business started in 2015. Our goal is to produce outdoor furniture, where families can gather to share and make memories together. Our furniture is designed for durability, comfort and low maintenance. We hope you will enjoy your furniture for many years.

Thank you for choosing Buckeye Poly Furniture!

Sincerely,

Aden Troyer

Michael Troyer

Worry-Free Outdoor Living

Designed for comfort and beauty, Tangent sustainable lumber looks like wood, but requires none of the maintenance. Made from recycled plastics, our HDPE material is easy to clean and resistant to water, mildew, moisture, insects, UV rays and chemicals. No matter what life throws at it, outdoor furniture made with Tangent is built to last.



MADE FROM MILK JUGS AND RECYCLED PLASTICS

Tangent proudly manufactures recycled plastic boards using post-industrial and post-consumer HDPE plastic like milk jugs and laundry detergent bottles. Our products meet criteria for Green Circle Certification. We also use a closed-loop manufacturing process that produces minimal greenhouse gases. Our materials are 100% recyclable.




CONFIDENTLY DURABLE

No rotting, splintering or peeling with materials that stand the test of time.



LASTING BEAUTY

Colors and textures remain flawless with no painting or staining required.



SUSTAINABLY MADE

Recycled materials create an unrivaled performance lumber.



EASE OF CARE

Simply wash with soap and water; no need to waterproof.



MADE IN THE USA

Our products are made in the United States.



GENERAL CLEANING

- Scrub boards with soap and water solution using a soft sponge or plastic-bristled brush.
- You can use a soft-bristled toothbrush to clean spaces that are hard to reach.
- To remove surface dust, just wash furniture with cold, clear water.



DEEP CLEANING

- A pressure washer can be used on the lightest setting to deep clean your furniture.
- It is not recommended to use more than 1,500psi.
- Keep the tip of the pressure washer at least 10-12 inches away from the furniture so it does not damage the lumber.

STAIN CHART

STAIN	RECOMMENDED CLEANING PROCESS
Pencil Marks	Use a mild dish detergent and water to saturate the stain. Rinse clean with water.
Ink/Marker	Use a mild dish detergent and water to saturate the stain. Rinse clean with water. For tougher stains, treat area with a penetrating oil. Wipe off and wash clean with water and a mild dish detergent.
Grease or Oil Stain	Use a mild dish detergent and water to saturate the stain. Rinse clean with water.
Embedded Dirt	Use a mild dish detergent to saturate the area. Scrub with a soft-bristled brush. Rinse clean with water.
Wine	Use a mild dish detergent to saturate the area. Scrub with a soft-bristled brush and rinse clean with water.
Chewing Gum	Coat penetrating oil over the area. Gently pry up on any hard pieces with a plastic putty knife. Utilize a soft brush and acetone solvent to remove any fine debris and clean out any crevasses. Rinse area clean with water.
Bird Droppings	Use a mild dish detergent to saturate the area. Scrub with a soft-bristled brush and rinse clean with water.
Stains and Scuffs	A foam eraser sponge may be used for stubborn marks.
Iron and Rust	For tough iron and rust stains, saturate with a heavy-duty rust remover and scrub with a soft-bristled brush.

Always read and follow the product manufacturers' specific instructions before using any cleaning product. Always wear approved safety glasses, gloves, face shield or goggles when operating cleaning equipment. If using alternative cleaning solutions than those outlined above, it is recommended to test the solution on an inconspicuous area of the lumber to make sure it does not harm the surface. For more information visit tangentmaterials.com.



36" Sq Base Firepit
 BP300SBF36
 25" H x 36" W



36" Round Base Firepit
 BP303RF
 25" H x 36" W



48" Sq Base Firepit
 BP304SBF48
 28" H x 48" W



48" Round Base Firepit
 BP301RF
 28" H x 48" W



Cushion Love Seat
BP221CLS
36" D x 36" H x 54" W
Seat - 17" H x 23" D x 46" W



Cushion Sofa
BP222CS
36" D x 36" H x 76" W
Seat - 17" H x 23" D x 69" W



Cushion Chair
BP220CC
36" D x 36" H x 32" W
Seat - 17" H x 23" D x 23" W



Cushion Swivel Glider
BP225CSG
36" D x 36" H x 32" W
Seat - 17" H x 23" D x 23" W



Cushion Love Seat Glider
BP2228CLG
36" D x 36" H x 54" W
Seat - 17" H x 23" D x 46" W



Cushion 2' Glider
BP227C2G
36" D x 36" H x 32" W
Seat - 17" H x 23" D x 23" W



Poly Cupholder
BP98PC



Cushion Ottoman
BP229CO
17" D x 15" H x 20" W



Cushion 3 Piece Sectional
BP226C3
36" D x 36" H - Right 90" W - Left 114" W
Seat - 17" H x 23" D



Cushion Chaise Extension
BP231CE
36" D x 17" H 23" W



Cushion Footstool
BP230CF
24" D x 17" H 24" W



Regal End Table w/ Shelf
BP223RET
22" D x 24" H 22" W



Regal Coffee Table 36" Long
BP224RCT
22" D x 18" H 36" W



Regal Coffee Table 42" Long
BP232RCT42
22" D x 18" H 42" W



Cushion 4' Porch Swing
BP218C4PS
36" D x 31" H 54" W
Seat x 23" D x 46" W



Cushion 6' Porch Swing
BP219C6PS
36" D x 31" H 76" W
Seat - Adj. Height x 23" D x 69" W



Contour Back 5' Glider Settee
 BP106CB25GS
 29" D x 42" H 70" W
 Seat - 18" H x 19" D x 60" W



Contour Back 5' Glider
 BP105CB5G
 29" D x 42" H 70" W
 Seat - 18" H x 19" D x 60" W



Contour Back 2' Swivel Glider
 BP103CB2SG
 29" D x 42" H 32" W
 Seat - 18" H x 19" D x 22.5" W



Contour Back 2' Glider
 BP102CB2G
 29" D x 42" H 32" W
 Seat - 18" H x 19" D x 22.5" W



Contour Back Chat Chair
BP100CBCC
29" D x 42" H x 32" W
Seat - 18" H x 19" D x 22.5" W



Contour Back 4' Glider
BP104CB4G
29" D x 42" H x 57" W
Seat - 18" H x 19" D x 48" W



Contour Back 4' Porch Swing
BP107CB4S
29" D x 33" H x 57" W
Seat - Adj. Height x 19" D x 48" W



Contour Back 5' Porch Swing
BP108CB5S
29" D x 33" H x 70" W
Seat - Adj. Height x 19" D x 60" W



Contour Back 5' Swing Settee
BP109CB5SS
29" D x 33" H x 70" W
Seat - Adj. Height x 19" D x 60" W



Sterling Rectangle Bar Table
BP363SRB
44" D x 42" H x 44" W



Sterling Rectangle Counter Table
BP355SRC
44" D x 36" H x 72" W



Sterling Rectangle Dining Table
BP347SRD
44" D x 30" H x 96" W



Also available in:



Sterling Dining Side Chair
 BP165SDSC
 26" D x 42" H x 21" W
 Seat - 18" H x 18" D x 20.5" W

Sterling Counter Side Chair
 BP166SCSC
 26" D x 42" H x 21" W
 Seat - 24" H x 18" D x 20.5" W



Sterling Dining Chair
 BP171SDC
 26" D x 42" H x 26" W
 Seat - 18" H x 18" D x 20.5" W



Sterling Counter Chair
 BP177SCC
 26" D x 42" H x 26" W
 Seat - 24" H x 18" D x 20.5" W



Sterling Bar Chair
 BP179SBC
 26" D x 48" H x 26" W
 Seat - 30" H x 18" D x 20.5" W



Sterling Dining Swivel Chair
 BP172SDSC
 26" D x 42" H x 26" W
 Seat - 18" H x 18" D x 20.5" W



Sterling Counter Swivel Chair
 BP174SCSC
 26" D x 42" H x 26" W
 Seat - 24" H x 18" D x 20.5" W



Sterling Bar Swivel Chair
 BP176SBSC
 26" D x 48" H x 26" W
 Seat - 30" H x 18" D x 20.5" W



60" Sterling Dining Table
 BP184SDT
 30" H x 60" round



48" Sterling Counter Table
 BP175SCT
 36" H x 48" round



36" Sterling Bar Table
 BP173SBT
 42" H x 36" round



Adirondack 5' Glider Settee
 BP76A5GS
 29" D x 42" H x 67" W
 Seat - 17.5" H x 19" D x 59" W



Adirondack 5' Glider
 BP75A5G
 29" D x 42" H x 67" W
 Seat - 17.5" H x 19" D x 59" W



Adirondack 2' Swivel Glider
 BP73A2SG
 29" D x 42" H x 31" W
 Seat - 17" H x 18.5" D x 22.5" W



Adirondack Gliding Ottoman
 BP124GO
 19.5" D x 12" H x 17.5" W



Adirondack 2' Glider
 BP72A2G
 29" D x 42" H x 31" W
 Seat - 17" H x 18.5" D x 22.5" W



Adirondack Balcony 2' Glider
BP79AB2G
29" D x 48" H x 31" W
Seat - 23" H x 18.5" D x 22.5 W




Adirondack Chat Chair
BP65ACC
26" D x 40" H x 27" W
Seat - 18" H x 18" D x 20.5" W



Adirondack 4' Glider
BP74A4G
29" D x 42" H x 55" W
Seat - 17.5" H x 19" D x 48" W

Adirondack Sloping Footrest
BP67SF
25" D x 14.5" H x 18" W



Adirondack Chaise Lounge
BP77ACL
74" D x 45" H x 32" W
Seat - 16" H x 50" D x 23" W



Chaise Lounge
BP78PBCL
74" D x 45" H x 32" W
Seat - 16" H x 48" D x 23" W



Economy End Table w/ Shelf
BP61EETWSH
18" D x 18" H x 15.5" W



Folding End Table
BP125FET
18" D X 21.5" H X 20" W



Adirondack 4' Porch Swing
BP54A4S
29" D x 33" H x 55" W
Seat - Adj. Height x 19" D x 48" W



Adirondack 5' Swing Settee
BP56A5SS
29" D x 33" H x 67" W
Seat - Adj. Height x 19" D x 59" W



Adirondack 5' Porch Swing
BP55A5S
29" D x 33" H x 67" W
Seat - Adj. Height x 19" D x 59" W



Regal porch Rocker
BP80RPR
34" D x 46" H x 27" W
Seat - 18" H x 19" D



Adirondack Chair
BP70AC
34" D x 38" H x 28" W
Seat - 15" H x 19.5" D x 22.5 W



Adirondack Folding Chair
PB71AFC
34" D x 38" H x 28" W
Seat - 15" H x 19.5" D x 22.5" W



Adirondack Child's Chair
BP50ACC
27" D x 28" H x 21.5" W
Seat - 8.5" H x 9.5" D x 16" W



Toddler's Chair
BP51TC
20" D x 20.5" H x 16" W
Seat - 12" H x 15" D x 11" W



Berkley Counter Table
BP17BCT
27.5" D x 36" H x 50" W



Berkley Pub Table
BP16BPT
27.5" D x 42" H x 50" W



Berkley Counter Stool
BP14BCS
16" D x 24" H x 18.5" W



Berkley Pub Stool
BP15BPS
16" D x 30" H x 18.5" W



Portland Balcony Counter Chair
BP241PBCC
27" D x 48" H x 27" W
Seat - 24" H x 18" D x 20.5" W



Portland Balcony End Table
BP240PBET
24.5" D x 36" H x 17.5" W



Portland Balcony Bar Chair
BP242PBBC
27" D x 54" H x 27" W
Seat - 30" H x 18" D x 20.5" W



Berkley Side Chair
BP100BDSC
26" D x 36" H x 21" W
Seat - 18" H x 18" D x 20.5" W



Berkley Counter Side Chair
BP102BCSC
26" D x 42" H x 21" W
Seat - 24" H x 18" D x 20.5" H



Berkley Bar Side Chair
BP104BBSC
26" D x 48" H x 21" W
Seat - 30" H x 18" D x 20.5" H



Berkley Dining Chair
BP110BDSC
26" D x 36" H x 27" W
Seat - 18" H x 18" D x 20.5" W



Berkley Counter Chair
BP112BCSC
26" D x 42" H x 27" W
Seat - 24" H x 18" D x 20.5" W



Berkley Bar Chair BP114BB-SC
26" D x 48" H x 27" W
Seat - 30" H x 18" D x 20.5" W



Berkley Dining Swivel Chair
BP111BDCS
26" D x 36" H x 27" W
Seat - 18" H x 18" D x 20.5" W



Berkley Counter Swivel Chair
BP113BCSC
26" D x 42" H x 27" W
Seat - 24" H x 18" D x 20.5" W



Berkley Bar Swivel Chair
BP115BBSC
26" D x 48" H x 27" W
Seat - 30" H x 18" D x 20.5" W



Berkley 4' Bench
BP26B4B
26" D x 36" H x 55" W
Seat - 18" H x 18" D x 48" W



Berkley 6' Backless Bench
BP28B6BB
13.75" D x 18" H x 72" W



Berkley Dining Table
BP154BDT
44" D x 30" H x 72" W



Berkley Counter Table
BP151BCT
44" D x 36" H x 44" W



Berkley Conference Dining Table
BP298BCDT
44" D x 30" H x 96" W



Berkley Conference Counter Table
BP291BCCT
44" D x 36" H x 72" W



Berkley Chaise Lounge
BP25BCL
74" D x 45" H x 34" W
Seat - 16" H x 52" D x 23" W



Berkley 4' Porch Swing
BP29B4PS
29" D x 33" H x 57" W
Seat - Adj. Height 20" D x 48" W



Berkley 5' Porch Swing Settee
BP13B5SS
29" D x 33" H x 69" W
Seat - Adj. Height 20" D x 60" W

Also available in:

Berkley 5' Porch Swing
BP12B5PS
29" D x 33" H x 69" W
Seat - Adj. Height 20" D x 60" W



Berkley Adirondack Chair
 BP10BAC
 32" D x 37" H x 32" W
 Seat - 15" H x 21.5" D x 22.5" W



Berkley Loveseat
 BP19BALS
 32" D x 37" H x 57" W
 Seat - 15" H x 21.5" D x 48" W



Berkley Chat Chair
 BP18BCC
 27" D x 37" H x 31" W
 Seat - 17" H x 18" D x 20.5" W

Berkley Swivel Chat Chair
 BP11BSCC
 27" D x 37" H x 31" W
 Seat - 17" H x 18" D x 20.5" W





Berkley 2' Glider
BP20B2G
29" D x 41" H x 32" W
Seat - 17" H x 18" D x 22.5" W



Berkley 4' Glider
BP22B4G
29" D x 41" H x 57" W
Seat - 17" H x 18" D x 48" W



Berkley 5' Glider
BP23B5G
29" D x 41" H x 69" W
Seat - 17" H x 18" D x 60" W



Berkley Counter End Table w/ Shelf
BP31BETWSH
16.5" D x 30" H x 24" W



Berkley End Table w/ Shelf
BP30BETWSH
16.5" D x 24" H x 24" W



Berkley Small End Table w/ Shelf
BP32BSETWSH
16.5" D x 18" H x 18" W



Berkley 5' Glider Settee
BP24B5GS
29" D x 41" H x 69" W
Seat - 17" H x 18" D x 60" W



Berkley 2' Swivel Glider
BP21B2SG
29" D x 41" H x 32" W
Seat - 17" H x 18" D x 22.5" W



6' Picnic Table
BP43PT6
60" D x 30" H x 72" W
Top is 33" x 72"



54" Half Table/Bench
BP46PTB54
30" H x 54" W



7' Walk-In Picnic Table
BP42PT7WI
60" D x 30" H x 84" W
Top is 33" x 84"

3' Child's Picnic Table
BP45CPT





Octagon Picnic Table
BP41OCT56
96" W x 30" H x 96" W
Top is 56"



X-Back Side Dining Chair
BP402XBSC
26" D x 38" H x 21" W
Seat - 18" H x 18" D



X-Back Side Counter Chair
BP403X BCSC
26" D x 44" H x 21" W
Seat - 24" H x 18" D



X-Back Dining Arm Chair
BP400XBAC
26" D x 38" H x 21" W
Seat - 18" H x 18" D



X-Back Arm Counter Chair
BP401XBCAC
26" D x 44" H x 21" W
Seat - 24" H x 18" D



6' X-Base Bench
BP276XBDT
13.75" D x 18" H x 72" W



7' X-Base Bench
BP287XBB7
13.75" D x 18" H x 84" W



X-Base Dining Table
BP276XBDT
44" D x 30" H x 84" W



X-Base Counter Table
BP273XBCT
44" D x 36" H x 72" W

STANDARDS



Tudor Brown



Cedar
N/S



Weathered Wood



Dark Gray



Light Gray



Cherrywood



Black



White



Ivory



Turf Green



Patriot Blue



Blue
N/S



Cardinal Red
N/S

BRIGHTS



Bright Orange
N/S



Lemon Yellow
N/S



Aruba Blue



Powder Blue
N/S



Tropical Lime
Green
N/S



Bright Purple
N/S



Pink
N/S

PREMIUM WOODGRAIN



Coastal Gray



Driftwood Gray



Birchwood



Natural Teak
N/S



Antique Mahogany



Brazilian Walnut



Seashell
N/S

* N/S = Non-Stock

Please allow extra lead time to get these colors in.

We use Sunbrella Fabrics!

Here are some of our most popular fabrics...



Berenson Tuxedo
8521-0000



Brannon Redwood
5612-0000



Brannon Whisper
5621-0000



Cabana Regatta
58029-0000



Canvas Aruba
55416-0000



Canvas Burgundy
5436-0000



Canvas Heather Beige
5476-0000



Canvas Henna
5407-0000



Canvas Navy
5439-0000



Cast Slate
40434-0000



Echo Ash
57005-0000



Echo Midnight
8076-0000



Frequency Ash
56092-0000



Gateway Mist
58039-0000



Harwood Crimson
5603-0000



Milano Char
56079-0000



Model Sand
44465-0001



Paradigm Stone
40484-0001



Peyton Granite
56075-0000



Spectrum Dove
48032-0000

